

Instructions for fitting door-billboards to internal doors

before



after



Dear customer,

Many thanks for your purchase of a door billboard. In order to make it as easy as possible for you to fit the billboard, we would ask you to carefully read through the instructions.

style-your-door-Team


Please note that the door billboards are designed for use only with smooth internal doors. Any kind of door material is suitable. The door billboards come in the following size:
2.10 m high x 0.90 m wide.

If you nonetheless wish to use the door billboard on an external door which is protected from the weather, we recommend that you seal the edges of the film (e.g. using transparent adhesive tape in order to protect the rear of the film from damp penetration.)

Brief instruction:



Remove the door handle



Measure the internal door



Unpack and spread out the motif



Cut the motif and adhesive tape to size



Clean the edges of the internal door



Fix the adhesive tape to the door



Attach the door billboard to the internal door



Mark the position of the door handle and cut an aperture for it



Finished!

This is how easy it is:

Your complete set

Your door billboard comes complete with a separate, double-sided adhesive tape and can be attached immediately!

To fit your door billboard, you will need:

- Around 15 – 30 minutes (plus 15 minutes waiting time)
- Possibly someone to help you
- A measuring tape or ruler
- A felt pen
- A cutter / carpet knife
- Cleaning agent, e.g. spirits
- Dry cleaning cloth
- Screwdriver

Please note that the door billboards are only suitable for smooth interior doors. It doesn't matter what material (metal, wood, plastic, glass, etc.) your interior door is made from.

The standard size of the door billboard is: Height 2.10 m x width 0.90 m.

Preparation

Ideally, remove the door handle using a screwdriver.

You can of course also mark the location of your door handle on the door billboard and then cut this section out of the film. This won't produce as nice a result as when you remove the handle, however.

Please note: If you do remove the handle, place something between the door and the frame so that you do not shut the door accidentally. After all, if there's no handle on the door, you can't open it again and you might inadvertently lock yourself in!

Measure and cut to size if necessary

Spread the door billboard out in front of you. The upper edge with the pre-fitted double-sided adhesive tape is

your guide line. This edge, for perspective reasons, must remain as it is. Please do not cut anything off it.

If the supplied format (210 cm x 90 cm) fits precisely over your door anyway, you won't need to worry about cutting the film to size.

Take a cutter or pair of scissors and cut the door billboard to the exact dimensions of your internal door.

Watch out! Always use a protective underlay to prevent damage to floors, tables or other surfaces when cutting the billboard with a knife.

Always cut parallel to the edge when trimming off any excess! Make sure that you cut the same amount from both sides in order to preserve the symmetry of the motif.

The adhesive tape

You now need to use the double-sided tape supplied with the billboard. Cut lengths of tape corresponding to the height and width of your door.

The double-sided tape has already been affixed to the master edge of the door billboard i.e. at the top.

Using cleaning fluid, e.g. white spirit, clean the door edges to the width of the adhesive tape.

Before you do this, always carry out a test in an inconspicuous place to avoid damage to paint or discolouration.

Once the cleaning agent has dried, secure the double-sided adhesive tape to the outer edges of your interior door – on the left, the right and along the bottom. As you do so, you must absolutely ensure that the adhesive tape is affixed to your interior door securely and smoothly. Smooth it over evenly as you go along.

Wait for around 10 – 15 minutes until the adhesive tape is securely adhered to the interior door.

Then pull the protective film off the double-sided adhesive tape in order to secure the door billboard in place.

You can now attach the door billboard to your internal door.

It's best done by two people, but of course you can do it on your own! While you do this, also remove the protective film from the adhesive film that's already attached to the door billboard.

Start now at the guide line (top) and press the door billboard onto the door. Hold the bottom section of the door billboard away from the door. Now slowly smooth from top to bottom and use light pressure to press the door billboard onto your interior door (if you have not removed the door handle, now push the door handle through the previously-cut opening).

**Attach the door handle.
Does everything fit properly?
Perfect - that was it!
Your door billboard from style-your-door.com is ready to use!**

Important! Of course, you can clean the door billboard at any time with regular household cleaning agents and wipe it with a damp cloth. Avoid abrasive cleaning agents, however, since these can damage the door billboard's coloured surface.

Enjoy your door billboard!

We will of course be happy at any time to answer any questions and respond to any suggestions that you might have.

style-your-door.com
Neumarkter Str. 28
D-81673 München
Tel.: +49.89.41 3691 11
Fax: +49.89.41 3691 41
service@style-your-door.com

Warning!

Please note that it is very difficult for us to process returns of door billboards that we can't resell (e.g. because they have already been cut to size, damaged, creased or previously attached to a door). Please refer to the section on returns procedure.

We cannot exclude the possibility that using or removing the door billboard after use may lead to damage to the surface to which it has been affixed. Possible damage in particular includes surface flaking when the adhesive tape is removed from the door

surface. We strongly recommend that you carry out a test on an inconspicuous part of the door surface prior to applying the adhesive tape.